



SET TRENCH DRAIN IN CHANNEL SURROUNDED BY 4" OF CONCRETE WITH A MINIMUM OF 2,500 PSI. SLOPE CONCRETE OFF THE TOP OF AND AWAY FROM THE DRAIN.



TECHNICAL SERVICES
1-888-825-4716
techservice@ndspro.com

TYPICAL EZ-TRACK INSTALLATION

FULL/PARTIAL CONCRETE ENCASMENT

N. T. S.